



YH2 系列高转差率三相异步电动机

YH2 SERIES HIGH SLIP THREE
PHASE ASYNCHRONOUS MOTOR

使用说明书

Operation Manual

安徽皖南电机股份有限公司


Anhui Wannan Electric Machine Co.,Ltd

衷心感谢您选购、使用皖南电机。

在使用电动机之前，请扫码仔细阅读本说明书，以便您正确的使用和维护。

本产品使用说明

1. 电源电压应与电机铭牌规定值相符，接到电机端子处的电压降应低于 2%。
2. 电机接线按铭牌上的规定，接成 Y 或 Δ ，接线方法如下图所示：




3. 电机接线盒内设有接地端子，应可靠接地。
4. 电机安装使用前，用 500V 兆欧表测得其对地绝缘电阻在室温时应不低于 $5M\Omega$ ，否则，需用低于 120°C 的热烘温度烘干后，方可使用。
5. 电机安装后，在启动前，需用手拨动转轴，应灵活转动。
6. 电机空载试转时，若转动方向与要求不符，则将任意两根电源引接线对调即可，（注意：若所配套的主机不允许逆转时，则应将电机转轴与配套主机脱开，进行试转，以保安全）。
7. 电机表面应保持清洁，进风口不应堵塞。
8. 电机使用的环境最高温度为 40°C ，最低温度不得低于 -15°C ；海拔高度不超过 1000m。
9. 电机必须定期（一般运行 5000h 左右）拆检，清除内部积尘污，清洗轴承，更换轴承中的润滑脂（3# 锂基脂）。全封闭轴承在使用寿命期内可不必更换润滑脂。
10. 电机运行时，若发生异常情况，如怪声、焦味、冒烟等应立即停机检查，待故障清除后，方可使用，常见故障如下：
 - 1) 电机为缺相运转；
 - 2) 电机的电源电压过低或过高，即超出额定电压的 95%–105% 范围。
 - 3) 加在电机端子上的三相电源电压不平衡度超过 5%。
 - 4) 电机在过载下运转。
 - 5) 电机连续起动超过 3 次。
 - 6) 电机通风及冷却效果不良。
 - 7) 电机轴承损坏等。

We are truly grateful for your purchasing of Wannan Motors. Before using the motor, please scan the QR code to read the manual so as to use and maintain the motor in a right way.

1. Check and make sure whether the power supply voltage is consistent with the motor's nameplate or not. The voltage drop on motor terminal should be lower than 2% of the rated voltage.

2. Connect the wires as connection diagram of Y or Δ type. The connections list see below:



3. There is a grounding terminal in terminal box, check and ensure the motor is grounded safely.

4. Before installation, measure insulation resistance of the motor with 500V meg-ohm meter. The value should be no less than 5 M Ω . Otherwise the motor must be dried in the oven with the temperature lower than 120 $^{\circ}$ C .

5. Rotate the shaft manually and ensure the rotation is flexible and smooth.

6. Start the motor for no-load test running. Make sure the direction of rotation is correct. Otherwise, interchange any 2 of the 3 connecting.

7. Keep the motor clean and in good ventilation.

8. Environment temperature for application should not exceed 40 $^{\circ}$ C . The altitude should less than 1000m above sea level.

9. The motor needs regular inspection (usually run around 5000 h), which includes clearing internal dust pollution, cleaning bearing, replacing grease in the bearing (3 # lithium base grease is recommended).

10. If abnormal problems are found, such as strange noise, burned smell or smoking, etc, the motor should be stopped immediately; and restart the motor till all the problems have been settled.

Common faults are as follows:

- 1) Non-full phase operation
- 2) Voltage fluctuation of the supplied power exceed 95% ~ 105% of the rated voltage.
- 3) Three-phase power supply voltage unbalance more than 5%.
- 4) Overload operation.
- 5) Continuously start more than three times
- 6) Poor ventilation and cooling effect.
- 7) Bearing damage.

敬告用户：

请您按照本使用说明书的规定，正确地使用和储存电动机，我们将为您提供优质、快捷的服务。

在电动机使用过程中，您如有什么疑惑请与我们联系，我们将及时给予您满意的解答；您有什么良好的建议请向我们提出，以便我们改进，为您提供优质、快捷的服务。

安徽皖南电机股份有限公司对本使用说明书保留最终解释权。

请勿在未事先获得安徽皖南电机股份有限公司书面许可的情况下向第三方复制、公布或者使用本使用说明书内容。

Dear user,

Please use and store the motor right following the instruction of the manual. We will make our effort to provide you with high-quality and prompt service. Contact us if you had any questions in application, and we will offer you timely and effective resolution; let us know if you had any advices or suggestions, with which we can improve ourselves and make service better. Anhui Wannan Motor Co., Ltd. reserves the right of final interpretation of the user manual. No copy, disclosing or using of the content of this user manual to third parties prior to written permission from Anhui Wannan Motor Co., Ltd.

安徽皖南电机股份有限公司

Anhui Wannan Electric Machine Co.,Ltd

地址：安徽省泾县泾川镇南华路 86 号

Address: No.86 Nanhua Road Jingxian County Anhui Province P.R.C

销售处 Sales department: 400-111-0563 0563-5031908 5031988

客户服务中心 Customer service center: 0563-5031953

企业管理处 Enterprises management department: 0563-5031954

质量检验处 Quality inspection department: 0563-5031910 5031985

传真 Fax: (0563) 5029999 5023698

网址 Website: <http://www.wnmotor.com>

E-mail: wndjc@wnmotor.com

邮编 Postal code: 242500

本说明书内容如有变动，恕不另行通知。

Content in the manual may be changed without prior notice.